


# Roper RTW4305XQ0 03 - AGITATOR, BASKET AND TUB PARTS



Roper Residential Roper RTW4305XQ0 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	63973	<a href="#">3362061</a>		Cap
2	<a href="#">358912</a>			Seal, Agitator Cap
3	<a href="#">358237</a>			Screw And Washer
4	<a href="#">3949550</a>			Washer
5	3361598	<a href="#">285727</a>		Agitator
6	3366877	<a href="#">80040</a>		Dog-Agitator
7	<a href="#">3363661</a>			Bearing, Driven Cam
8	3363662	<a href="#">285748</a>		Cam-Agitator
9	<a href="#">3360824</a>			Auger, Agitator
10	3350389	<a href="#">285587</a>		Washer
11	<a href="#">389386</a>			Agitator
12	8528150	<a href="#">W10445870</a>		Ring-Tub
13	<a href="#">3976308</a>			Gasket, Tub Ring
14	<a href="#">21366</a>			Nut, Spanner
15	8526017	<a href="#">W10389329</a>		Clothes Container, Assembly
16	<a href="#">387240</a>			Ring, Balance

17	W10297437	<a href="#">353244</a>	Hose, Pressure Switch
18	<a href="#">2219077</a>		Clip, Pressure Switch Hose
19	<a href="#">389140</a>		Tub Block, Basket Drive
20	<a href="#">63849</a>		Strain Relief, Power Cord
21	<a href="#">383727</a>		Gasket, Centerpodt

