


# Samsung DV306LEW/XAA 05 - DRUM



Samsung [Residential Samsung DV306LEW/XAA Dryer Parts](#) Parts Diagram 05 - DRUM  
 Click on the part number to view part

| Item | Original Part Number        | Replaced By                 | Status        | Part Description         |
|------|-----------------------------|-----------------------------|---------------|--------------------------|
| 1    | DC61-01521A                 | <a href="#">DC61-02613A</a> |               | Case Filter              |
| 2    | DC97-10362B                 |                             | Not Available | ASSY-S.DRUM FRONT        |
| 3    | DC97-08889A                 | <a href="#">35001150</a>    |               | Assembly-Guide Sensor    |
| 4    | DC61-01231A                 | <a href="#">35001241</a>    |               | Plate-Sensor             |
| 5    | DC61-01235A                 |                             | Not Available | GUIDE-SENSOR             |
| 6    | DC63-00675A                 |                             | Not Available | COVER-FILTER(B)          |
| 7    | DC63-00538A                 | <a href="#">35001144</a>    |               | Cover-Filter             |
| 8    | DC97-07523A                 | <a href="#">W10177428</a>   |               | Assembly, Roller-Support |
| 9    | DC60-60060A                 | <a href="#">35001133</a>    |               | Washer, Support          |
| 10   | DC60-50145A                 | <a href="#">23001661</a>    |               | Nut M10                  |
| 11   | <a href="#">6046-000310</a> |                             |               | Stand Off                |
| 12   | 6002-000231                 |                             | Not Available | Screw-Tapping (5)        |
| 13   | DC97-07526A                 | <a href="#">35001140</a>    |               | Assembly, Lint Duct      |
| 14   | DC97-10355A                 |                             | Not Available | ASSY-DRUM WRAPPER        |
| 15   | DC66-00436A                 |                             | Not Available | DRUM-LIFTER              |
| 16   | 6002-001204                 |                             | Not Available | SCREW-TAPPING            |

|    |             |                           |               |                                |
|----|-------------|---------------------------|---------------|--------------------------------|
| 17 | 6602-001314 | <a href="#">W10205415</a> |               | Belt                           |
| 18 | 6002-000239 |                           | Not Available | Screw-Tapping (10)             |
| 19 | DC66-00398B |                           | Not Available | DRUM-BACK;WINGS-DRYER          |
| 20 | DC61-01238A | <a href="#">35001145</a>  |               | Bracket, Upper Rear Bulkhead   |
| 21 | DC61-01237A | <a href="#">35001146</a>  |               | Channel Bracket, Rear Bulkhead |
| 22 | DC61-40081A | <a href="#">M0585401</a>  |               | Tie, Wire                      |
| 23 | DC97-07521A |                           | Not Available | ASSY-DUCT AIR                  |

