


Samsung WF316BAC/XAA 02 - CONTROL PANEL/HOUSING-DRAWER



Samsung [Residential Samsung WF316BAC/XAA Washer Parts](#) Parts Diagram 02 - CONTROL PANEL/HOUSING-DRAWER

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	DC97-10513C			Assembly-S.panel Control
2	DC66-00413A	34001419		Lever, Power
3	DC64-01105C		Not Available	BUTTON-PUSH(P)
4	Y00000000		Not Available	SEE NOTE WINDOW ENCODER CURRENTLY UNAVAILABLE
5	W10126754		Not Available	ASSY PCB PARTS(M)
6	DC97-10526A		Not Available	ASSY-KNOB ENCODER;FRONTIER,BBY
7	DC64-01132C		Not Available	BUTTON-ENCODER
8	Y00000000		Not Available	SEE NOTE ASSY-PANEL DRAWER CURRENTLY UNAVAILABLE
9	DC64-01113C		Not Available	HANDLE-DRAWER
10	DC67-00121B	34001401		Cap, Rinse
11	DC61-01171A	34001239		Separator
12	DC97-08774A	34001282		Drawer, Detergent
13	DC63-00516A		Not Available	COVER-DETERGENT

14	DC61-01170A		Not Available	BODY-DRAWER
15	DC97-08800A	34001284		ASSEMBLY-S Housing Drawer
16	DC67-00051B	34001210		Hose-Dispe
17	DC62-30314K			Valve-Water
18	DC65-00008A	596669		Clamp, Manifold
19	DC97-10417A		Not Available	ASSY-GUIDE WATER
20	DC67-00089F		Not Available	HOSE-WATER
21	DC61-01167C		Not Available	HOUSING-DRAWER(L);WF326LAW,PP
22	DC64-01084A		Not Available	KNOB-ENCODER(1);K4-PJT,ABS,-,-
23	DC97-07125C		Not Available	ASSY-HOUSING DRAWER
24	DC97-10335C		Not Available	ASSY-DRAWER
25	DC62-00142G			Valve, Water

the laundry company[®]

the laundry company[®]

the laundry company[®]