



Samsung WF316BAW 05 - TUB BACK



Samsung Residential Samsung WF316BAW Washer Parts Parts Diagram 05 - TUB BACK
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	DC69-00804A	34001296		Gasket, Tub
2	DC61-01257A	34001274		Spring, Suspension
3	DC67-00155A	34001295		Hose Exhaust
4	DC67-00123A	34001293		Hose, Exhaust
5	DC72-00035A	34001298		Clamp, Hose
6	Y00000000		Not Available	SEE NOTE ASSY-SEMI TUB BACK CURRENTLY UNAVAILABLE
7	6011-001554		Not Available	BOLT-ETC;M6,L56,ZPC3(WHT),SWRC
8	DC31-00049A	34001269		Motor-Drum
9	DC62-00156A	34001310		Seal-Oil
10	DC60-50148B	34001271		Nut, Pulley
11	DC60-60049A	34001273		Washer, Spring
12	6031-001531		Not Available	WASHER-PLAIN;SCP1,-,ID7,OD14,
"	DC60-60044B		Not Available	WASHER-PLAIN;SBC,ID8.4,OD30,T3

13	DC65-20008A		Not Available	CLAMP-CABLE;DA-2N,DONG-A,ELEC,
14	DC61-01431B	34001477		Bracket
15	Y00000000		Not Available	SEE NOTE BOLT-HEX CURRENTLY UNAVAILABLE
16	DC61-00219C	596669		Clamp, Manifold
17	DC67-00126A	34001294		Hose, Tub To Pump
18	DC65-00014A	34001289		Clamp, Hose
19	DC72-00001D	34001297		Clamp, Hose
20	DC61-01338A		Not Available	BRACKET-HOUSING BEARING
21	DC66-00343E		Not Available	DAMPER-SHOCK;GW-PJT,STEEL+PP+
22	DC61-01482A		Not Available	BRACKET-HEATER

the laundry company[®]

the laundry company[®]

the laundry company[®]