


Samsung WF316LAS 02 - CONTROL PANEL/HOUSING-DRAWER



Samsung Residential Samsung WF316LAS Washer Parts Parts Diagram 02 - CONTROL PANEL/HOUSING-DRAWER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	DC97-10513B		Not Available	ASSY-S.PANEL CONTROL
2	DC66-00413A	34001419		Lever, Power
3	DC64-01105B		Not Available	BUTTON-PUSH(P)
4	Y00000000		Not Available	SEE NOTE WINDOW ENCODER CURRENTLY UNAVAILABLE
5	W10126756		Not Available	ASSY PCB PARTS(M)
6	DC97-10511A			Assembly-Knob Encoder
7	DC64-01108B		Not Available	BUTTON-ENCODER
8	DC97-10960B		Not Available	ASSY-PANEL DRAWER
9	DC64-01113B		Not Available	HANDLE-DRAWER
10	DC67-00121B	34001401		Cap, Rinse
11	DC61-01171A	34001239		Separator
12	DC97-08774A	34001282		Drawer, Detergent
13	DC63-00516A		Not Available	COVER-DETERGENT
14	DC61-01170A		Not Available	BODY-DRAWER
15	DC97-08800A	34001284		ASSEMBLY-S HOUSING DRAWER

16	DC67-00051B	34001210	Hose-Dispe
17	DC62-30314K		Valve-Water
18	DC65-00008A	596669	Clamp, Manifold
19	DC97-10417A		Not Available
			ASSY-GUIDE WATER
20	DC67-00089F		Not Available
			HOSE-WATER
21	DC61-01167C		Not Available
			HOUSING-DRAWER(L);WF326LAW,PP
22	DC64-01084A		Not Available
			KNOB-ENCODER(1);K4-PJT,ABS,-,-
23	DC97-07125C		Not Available
			ASSY-HOUSING DRAWER
24	DC97-10336B		Not Available
			ASSY-DRAWER
25	DC62-00142G		Valve, Water

