


Whirlpool 1CLSQ9549PG1 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: 1CLSQ9549PW1, 1CLSQ9549PG1
(White/Grey) (Biscuit/Gold)

AUTOMATIC
WASHER



10-05 Litho in U.S.A. (drd)

1

Part No. 8190849

Whirlpool [Residential Whirlpool 1CLSQ9549PG1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3958075		Not Available	Installation Instructions
"	3955907		Not Available	Feature Sheet
"	8578232		Not Available	Use & Care Guide
"	3957349		Not Available	Energy Guide
"	8566203		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	8543451	8543447		Top
"	8543452	8543448		Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
"	3954357			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel

7	3976348		Absorber, Sound
8	3351614		Screw, Gearcase Cover Mounting
10	9724509		Bumper, Lid
11	8318084		Switch, Lid
12	3357011	308685	Side Trim)
13	355274	W10119828	Screw, Lid Hinge Mounting
14	21097		Pad, Lid Hinge
15	8559336	W10225136	Hinge 7 Pad Assembly
16	91770		Hinge, Lid
18	8319539		Bearing, Lid Hinge
19	8558398	W10193861	Lid
"	8558399	W10193862	Lid
28	3390631		Screw, 10-16 X 3/8
31	3955788		Cover, Dispenser
32	8519517		Dispenser, Bleach

