


Whirlpool 1CLSR9434PQ1 01 - TOP AND CABINET PARTS



10-05 Litho in U.S.A. (drd)

1

Part No. 8180853

Whirlpool [Residential Whirlpool 1CLSR9434PQ1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3958075		Not Available	Installation Instructions
"	8578232		Not Available	Use & Care Guide
"	3955907		Not Available	Feature Sheet
"	3957470		Not Available	Energy Guide
"	8541944		Not Available	Wiring Diagram
"	N/A		Not Available	Following May Be Purchased
"	N/A		Not Available	DO-IT-YOURSELF REPAIR MANUALS
"	4313896			Do-It-Yourself Repair Manuals
2	8318064			Top
"	8318066			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
"	3954357			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel

7	3362952		Dispenser, Bleach
8	3351614		Screw, Gearcase Cover Mounting
9	3357011	308685	Side Trim)
11	8318084		Switch, Lid
13	3351355	W10119828	Screw, Lid Hinge Mounting
15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542387	W10193857	Lid
"	8542384	3957520	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

the laundry company[®]

the laundry company[®]

the laundry company[®]