


# Whirlpool 1CLSR9434PT1 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 1CLSR9434PT1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	<a href="#">16123</a>		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	<a href="#">3400073</a>			Screw, Ground
3	8571377	<a href="#">89503</a>		Hose-Inlet
"	8571378	<a href="#">89503</a>		Hose-Inlet
4	<a href="#">9740848</a>			Screw, Mixing Valve Mounting
5	<a href="#">8568314</a>			Strap, Console
6	<a href="#">8318015</a>			Panel, Rear
7	<a href="#">62747</a>			Pad, Rear Panel
8	8559373	<a href="#">W10096921</a>		Drain Hose Assembly
9	<a href="#">8541942</a>			Timer, Control
10	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
11	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366847	<a href="#">W10337780</a>		Switch-WL

13	<a href="#">3948608</a>		Bracket, Control
14	661661	<a href="#">285800</a>	Cord-Power
15	3952821	<a href="#">285777</a>	Relief-Str
16	8271365	<a href="#">279962</a>	Endcap
"	8271368	<a href="#">279965</a>	Endcap
17	<a href="#">8572717</a>		Capacitor, Motor Start
18	3952164	<a href="#">285805</a>	Valve-Inlet
19	<a href="#">694419</a>		Mini-Buzzer
20	<a href="#">8318046</a>		Clip, Capacitor
21	301958	<a href="#">596669</a>	Clamp, Manifold
22	8541607	<a href="#">3357328</a>	Hose, Vacuum Break
23	370450	<a href="#">596669</a>	Clamp, Manifold
24	387606	<a href="#">3360977</a>	Break-Vac
25	303294	<a href="#">3367669</a>	Protector, Edge
26	<a href="#">8519200</a>		Support, Rear Panel
27	<a href="#">8541667</a>		Clamp, Hose
28	<a href="#">8541668</a>		Clamp, Hose
30	3363366	<a href="#">616099</a>	Clamp
31	8317496	<a href="#">285655</a>	Clamp, Hose
32	3951449	<a href="#">285871</a>	Hose
33	<a href="#">8055003</a>		Clip, Harness And Pressure Switch
34	<a href="#">8317975</a>		Restraint, Harness
35	661612	<a href="#">W10168256</a>	Switch, Water Temperature
36	<a href="#">3400818</a>		Screw, Timer Mounting
37	3949180	<a href="#">W10168257</a>	Switch, Rotary
39	<a href="#">3956559</a>		Panel, Console
"	<a href="#">3956560</a>		Panel, Console
41	<a href="#">8541669</a>		Bucket, Drain Hose
"	BLANK	Not Available	(Left Half)
42	<a href="#">8541658</a>		Bucket, Drain Hose
"	BLANK	Not Available	(Right Half)
44	<a href="#">8544943</a>		Knob, Timer
"	<a href="#">8544944</a>		Knob, Timer
45	<a href="#">8544947</a>		Dial, Timer
"	<a href="#">8544948</a>		Dial, Timer
46	<a href="#">8536939</a>		Clip, Knob
47	<a href="#">8544935</a>		Knob, Control
"	<a href="#">8544936</a>		Knob, Control
49	<a href="#">388326</a>		Screw, 8-18 X 1.25
50	62863	<a href="#">3390631</a>	Screw, 10-16 X 3/8
51	8271359	<a href="#">279962</a>	Endcap
"	8271362	<a href="#">279965</a>	Endcap
58	8541672	<a href="#">8577378</a>	U-Bend, Drain Hose
59	<a href="#">8539874</a>		Shield, Suds
60	3347868	<a href="#">W10339879</a>	Tie, Cable
61	<a href="#">3957015</a>		Wiring Harness
"	N/A	Not Available	FOLLOWING PARTS NOT ILLUSTRATED
"	<a href="#">3957361</a>		Miscellaneous Parts Bag