


Whirlpool 1CWGD5200VQ0 02 - CABINET PARTS



W10250091

3

Whirlpool [Residential Whirlpool 1CWGD5200VQ0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	4331106		Screw, No.10-32 X 7/16
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	8541400			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3404162			Clamp, Motor
7	3396805	280043		Panel-Rear
8	3980175			Clamp, Elbow
9	3406107			Door Switch Assembly
10	697773	3395530		Screw
11	3357011	308685		Side Trim)
12	W10041960			Spring, Door
13	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
14	342043	486146		Screw
15	8530603	8533643		Cabinet

16	98234		Clip, U-Bend
17	690363	18776	Lock, Front Top
18	3395197	279740	Panel
19	685203	279220	Clip
20	3389441		Door Catch Assembly
21	3390731		Seal, Door
22	337189		Clip, Hinge
23	694091		Trim, Side Right Hand
24	8066056		Hinge, Door
"	8066057		Hinge, Door
25	696144	279570	Latch
26	695737		Door, Rear
27	3393549		Door, Front
28	W10095180		Handle, Door
29	3406129		Seal And Bearing Assembly
30	3394975		Plug, Front Panel
31	344020	3401402	Cord, Power
32	3394083		Clip, Front Panel
33	8066217		Hinge, Top
34	691366		Idler And Pulley Assembly
35	8066065	341241	Belt
36	348780		Base, Motor
37	3400500		Bolt, 3405245 5/16-18 X 3/4
38	8066184		Pulley, Motor
39	W10194250	279827	Motor-Drve
40	W10121316		Plug, Multivent
41	8318272	W10465748	Burner-Gas
42	341029		Clamp, Pipe Door Spring

the laundry company[®]

the laundry company[®]