


# Whirlpool 1CWTW4840YW0 03 - BASKET AND TUB PARTS

## BASKET AND TUB PARTS

For Model: 1CWTW4840YW0  
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10444609

5

Whirlpool [Residential Whirlpool 1CWTW4840YW0 Washer Parts](#) Parts Diagram 03 - BASKET AND TUB PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8580006</a>			Dispenser, Fabric Softener
2	3354733	<a href="#">W10074580</a>		Cap, Barrier
3	<a href="#">W10072840</a>			Fabric Softener
4	<a href="#">W10003790</a>			Screw And Washer
5	<a href="#">3949550</a>			Washer
6	<a href="#">8578210</a>			Agitator, Complete Assembly
7	<a href="#">8537434</a>			Cam, Driven
8	3366877	<a href="#">80040</a>		Dog-Agitator
9	<a href="#">8055141</a>			Bearing-Driven Cam
10	<a href="#">8054468</a>			Auger, Agitator
11	<a href="#">8055228</a>			Spacer, Thrust
12	<a href="#">8578209</a>			Agitator, Complete Assembly
13	<a href="#">W10215108</a>			Ring, Tub
14	<a href="#">21366</a>			Nut, Spanner
15	W10358261	<a href="#">W10349185</a>		Basket
16	<a href="#">389140</a>			Tub Block, Basket Drive

17	<a href="#">W10339098</a>		Shield, Splash
18	W10238320	<a href="#">W10371566</a>	Tub-Outer
19	W10006371	<a href="#">W10324647</a>	Seal-Tub
20	<a href="#">W10215093</a>		Filter, Drain Pump
21	<a href="#">8533928</a>		Screw, 8-18 X 3/4
22	W10257088	<a href="#">W10349191</a>	Suspension
23	W10215136	<a href="#">W10440729</a>	Suspension
24	W10256551	<a href="#">W10440729</a>	Suspension
25	<a href="#">W10297439</a>		Harness, Lower
26	W10431037	<a href="#">353244</a>	Hose, Pressure Switch
27	<a href="#">W10005430</a>		Clamp, Pressure Hose Retainer
28	8533943	<a href="#">W10109200</a>	Screw, Baffle Mounting
30	<a href="#">8533540</a>		Retainer, Spring
31	<a href="#">8055140</a>		Spring, Compression
32	<a href="#">W10273613</a>		Retainer, Push In

