


Whirlpool 1DWTW5205SQ1 01 - TOP AND CABINET PARTS

TOP AND CABINET PARTS

For Model: 1DWTW5205SQ1
(White)



W10131599

2

Whirlpool [Residential Whirlpool 1DWTW5205SQ1 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10044800			Installation Instructions
"	W10096500		Not Available	Use & Care Guide
"	W10131599		Not Available	Repair Parts List
"	8565144		Not Available	Wiring Diagram
2	8318068			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	9724509			Bumper, Lid
8	3351614			Screw, Gearcase Cover Mounting
9	8318084			Switch, Lid
10	W10119872	W10119828		Screw, Lid Hinge Mounting
11	8318088			Hinge, Lid
12	54583			Hinge, Lid

13

[19119](#)

Bumper, Lid Hinge

14

[21258](#)

Bearing, Lid Hinge

15

8541774

[W10193857](#)

Lid

16

[3390631](#)

Screw, 10-16 X 3/8

