


Whirlpool 2DLSQ7533JQ5 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 2DLSQ7533JQ5 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	3179795			Screw, Ground
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	9740848			Screw, Mixing Valve Mounting
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559374	W10096921		Drain Hose Assembly
9	3954729			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366848	W10339229		Switch-WL

13	3948608		Bracket, Control
14	661661	285800	Cord-Power
15	8559349	285777	Relief-Str
16	8271365	279962	Endcap
17	3363920	3363920A	Adapter
18	3952164	285805	Valve-Inlet
20	694419		Mini-Buzzer
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	303294	3367669	Protector, Edge
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8541668		Clamp, Hose
29	285655		Clamp, Hose
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
34	8577375		Coupling, Drain Hose
35	661612	W10168256	Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	3949180	W10168257	Switch, Rotary
38	8572717		Capacitor, Motor Start
39	3954181		Panel, Console
40	8318046		Clip, Capacitor
42	8317975		Restraint, Harness
44	3957824		Knob, Timer
45	3957849		Dial, Timer
46	8536939		Clip, Knob
47	3957799		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271359	279962	Endcap
52	3347868	W10339879	Tie, Cable
53	8541672	8577378	U-Bend, Drain Hose
54	8539874		Shield, Suds
55	3956702		Harness, Wiring
56	8541669		Bucket, Drain Hose
57	8541658		Bucket, Drain Hose