


Whirlpool 2DLSQ8000JQ5 01 - TOP AND CABINET PARTS

TOP AND CABINET PARTS

For Model: 2DLSQ8000JQ5
(Designer White)



8316573

2

Whirlpool [Residential Whirlpool 2DLSQ8000JQ5 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8316567		Not Available	Installation Instructions
"	8539783		Not Available	Use & Care Guide
"	8543287		Not Available	Wiring Diagram
"	8316573		Not Available	Repair Parts List
2	8318064			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3976348			Absorber, Sound
8	3351614			Screw, Gearcase Cover Mounting
9	3357011	308685		Side Trim)
11	8318084			Switch, Lid
13	3351355	W10119828		Screw, Lid Hinge Mounting
15	8318088			Hinge, Lid

16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8542387	W1019385Z	Lid
20	9724509		Bumper, Lid
21	3390631		Screw, 10-16 X 3/8
22	3362952		Dispenser, Bleach

