


Whirlpool 2DLXR7244MQ2 02 - CONTROL AND REAR PANEL PARTS



Whirlpool Residential Whirlpool 2DLXR7244MQ2 Washer Parts Parts Diagram 02 - CONTROL AND REAR PANEL PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
2	9740848			Screw, Mixing Valve Mounting
3	8571377	89503		Hose-Inlet
"	8571378	89503		Hose-Inlet
4	3357027			Nozzle, Hose Drain
5	8568314			Strap, Console
6	3357978			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3956203			Timer, Control
10	3351614			Screw, Gearcase Cover Mounting
11	00767			Screw, 8A X 3/8 HeX Washer

11	30707		Head Tapping
12	3366847	W10337780	Switch-WL
13	3948608		Bracket, Control
14	661661	285800	Cord-Power
15	3952821	285777	Relief-Str
16	8271365	279962	Endcap
17	3179795		Screw, Ground
18	3952164	285805	Valve-Inlet
19	3363920	3363920A	Adapter
20	8318046		Clip, Capacitor
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	3976395		Restraint, Hose
26	8317959	W10358151	Drain Hose Assembly
27	3366912	356138	Clamp, Hose
28	8572717		Capacitor, Motor Start
29	356138		Clamp, Hose
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	8055003		Clip, Harness And Pressure Switch
34	285750	Not Available	(Kit-Adapter) (Includes. Item) (20. And 27.)
35	661614		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	303294	3367669	Protector, Edge
38	8536939		Clip, Knob
39	3954207		Panel, Console
40	8317975		Restraint, Harness
44	3957824		Knob, Timer
45	3957849		Dial, Timer
47	3957799		Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271359	279962	Endcap
58	3366913	3357331	Clamp, Drain
59	3956701		Harness, Wiring
"	N/A	Not Available	FOLLOWING PARTS NOT ILLUSTRATED
"	8541756	285654	Parts-Misc