


Whirlpool 2DWTW4740YQ0 02 - CONTROLS AND WATER INLET PARTS

CONTROLS AND WATER INLET PARTS

For Model: 2DWTW4740YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10451490

3

Whirlpool Residential Whirlpool 2DWTW4740YQ0 Washer Parts Parts Diagram 02 - CONTROLS AND WATER INLET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10365091			Panel, Console
2	8536939			Clip, Knob
3	8566035	8565957		Cap, End
4	8566032	8565954		Cap, End
5	8312709			Clip-Console
6	W10445371			Control Unit Assembly, Machine And Motor
7	W10420985			Panel, Console Rear Cover
8	1157158	489069		Xxscrew, 10-12 X 1/2
9	W10268910			Switch, Water Level
10	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
11	W10276649			Cord, Power
12	3400076			Screw, Bracket Mounting
13	W10034750			Timer Knob Assembly
14	W10034380			Knob, Control

15	W10285511		Switch, Rotary Encoder
16	W10291178		Harness, Upper
17	W10432360		Inlet Assembly, Water
18	W10352256		Valve, Water Mixing
19	W10441423		Vacuum Break
20	W10238347		Hose, Vacuum Break
21	W10117298	596669	Clamp, Manifold
22	W10344775		Harness, Valve
23	8281163		Screw, Dispenser Housing Mounting
24	3400818		Screw, Timer Mounting
25	W10348582		Cable Tie
26	W10251309		Pushbutton, Start
27	W10242307	16123	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
28	W10194210	89503	Hose-Inlet
"	W10196191	89503	Hose-Inlet
29	353362	285452	Hose Screen
30	W10269488		Connector- Hose, Y
31	3357450		Washer, Water Inlet Hose

