


# Whirlpool 3DWED5605SQ0 02 - CABINET PARTS



W10114524

3

Whirlpool Residential Whirlpool 3DWED5605SQ0 Dryer Parts Parts Diagram 02 - CABINET PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">693995</a>			Screw, Hex Head
4	<a href="#">8541400</a>			Bracket, Cabinet
5	<a href="#">3396795</a>			Cover, Terminal Block
6	<a href="#">3403630</a>			Plug, Strike Hole
7	3396805	<a href="#">280043</a>		Panel-Rear
8	3393008	<a href="#">308685</a>		Side Trim )
10	3406109	<a href="#">3406107</a>		Door Switch Assembly
11	697773	<a href="#">3395530</a>		Screw
12	<a href="#">3404413</a>			Plug, Hinge Hole
15	<a href="#">3394083</a>			Clip, Front Panel
16	3392100	<a href="#">49621</a>		Feet-Leveling
18	8530603	<a href="#">8533643</a>		Cabinet
19	<a href="#">98234</a>			Clip, U-Bend
20	690363	<a href="#">18776</a>		Lock, Front Top
21	3403444	<a href="#">279852</a>		Panel

23	685203	<a href="#">279220</a>	Clip
24	<a href="#">3389441</a>		Door Catch Assembly
27	342055	<a href="#">488627</a>	Screw
28	3405514	<a href="#">W10362431</a>	Hinge And Pin Assembly
29	<a href="#">279318</a>		Terminal Tinned And Brass Panel
33	<a href="#">3403431</a>		Strike, Panel
35	<a href="#">3402341</a>		Door, Inner
36	<a href="#">3402335</a>		Door, Front
37	<a href="#">3405184</a>		Handle, Door
38	<a href="#">3406129</a>		Seal And Bearing Assembly
39	<a href="#">694415</a>		Clip, Strain Relief
41	<a href="#">3397659</a>		Block, Terminal
42	<a href="#">279393</a>		Terminal Block Screw Kit
45	3387258	<a href="#">W10111542</a>	Cord, Power
51	<a href="#">8066217</a>		Hinge, Top
52	690046	Not Available	SCREW, SET 1/4 - 28 X 3/8
53	<a href="#">691366</a>		Idler And Pulley Assembly
56	8066065	<a href="#">341241</a>	Belt
57	<a href="#">348780</a>		Base, Motor
58	<a href="#">3400500</a>		Bolt, 3405245 5/16-18 X 3/4
59	<a href="#">685064</a>		Pulley, 50 Hz
60	<a href="#">3404162</a>		Clamp, Motor
61	<a href="#">3388235</a>		Switch, Centrifugal
62	685815	<a href="#">W10416572</a>	Motor-Drve
63	<a href="#">660658</a>		Clamp, Motor Mounting 343481 685441
64	<a href="#">690236</a>		Wire, Ground
67	<a href="#">3405246</a>		Seal, Door Push-To-Start
68	697776	<a href="#">4331106</a>	Screw, No.10-32 X 7/16

