


# Whirlpool 3LCD9100WQ1 02 - CABINET PARTS



W10396216

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4

Whirlpool [Residential Whirlpool 3LCD9100WQ1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10096918</a>			Cover, Terminal Block
2	3390814	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">W10080830</a>			Screw, 10-32 X 5/8
4	<a href="#">8565048</a>			Panel, Side
5	<a href="#">W10410873</a>			Assembly, Switch And Actuator
6	<a href="#">8519459</a>			Clip, Toe Panel
7	<a href="#">8565054</a>			Panel, Side
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">49252</a>			Plug, Multivent
13	<a href="#">W10344192</a>			Idler Assembly

14	<a href="#">279318</a>		Terminal Tinned And Brass Panel
15	<a href="#">8564011</a>		Bracket-Switch
16	<a href="#">8316644</a>		Power Cord, Strain Relief
17	<a href="#">3393657</a>		Restrainer, Belt
19	<a href="#">W10251066</a>		Assembly, Door Switch
21	8066115	<a href="#">3394331</a>	Plate Cover
22	<a href="#">8565083</a>		Ramp, Door
23	<a href="#">8565122</a>		Strike, Door
24	<a href="#">W10212660</a>		Pad, Sound Dampening
25	<a href="#">W10225178</a>		Base, Cabinet
26	<a href="#">W10225180</a>		Panel, Rear
27	W10289662	<a href="#">W10416574</a>	Motor-Drve
28	<a href="#">W10137398</a>		Stop, Top Panel
29	<a href="#">W10167237</a>		Pulley
30	<a href="#">W10131172</a>		Belt, Drive
31	<a href="#">3397659</a>		Block, Terminal
32	<a href="#">W10135695</a>		Bracket, Motor
33	<a href="#">279393</a>		Terminal Block Screw Kit
34	<a href="#">49026</a>		4" - 90° Elbow
35	3390647	<a href="#">488729</a>	Screw
36	<a href="#">8563747</a>		Exhaust Pipe Medium Pipe
37	<a href="#">8563750</a>		Exhaust Pipe
38	<a href="#">8563749</a>		Exhaust Pipe
40	<a href="#">8540621</a>		Panel, Toe
41	<a href="#">W10142290</a>		Screw, 8-18 X 5/16
42	<a href="#">3400934</a>		Assembly, Screw And Insulator
43	<a href="#">3388235</a>		Switch, Centrifugal
44	<a href="#">3387242</a>		Seal, Front Panel
45	<a href="#">3405160</a>		Belt, Drive
46	<a href="#">W10166301</a>		Control Board
47	<a href="#">8563727</a>		Bracket, Control
48	<a href="#">8565043</a>		Plug, Strip Front Panel
49	3357011	<a href="#">308685</a>	Side Trim )
50	<a href="#">W10255282</a>		Front Panel
51	<a href="#">W10259136</a>		Switch, Assembly
52	<a href="#">8318396</a>		Foam-Seal
53	<a href="#">3391943</a>		Boot, Foot
54	<a href="#">W10205520</a>		Transformer, 120 To 22.5
55	<a href="#">W10237958</a>		Transformer, 240 - 120
56	<a href="#">W10080820</a>		Screw, 8-18 X .298
NI	279818	<a href="#">W10470674</a>	Dryer Exhaust Kit