


Whirlpool 3LCGD9100WQ1 02 - CABINET PARTS



Whirlpool [Residential Whirlpool 3LCGD9100WQ1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096918			Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	4331106		Screw, No.10-32 X 7/16
4	8565048			Panel, Side
5	W10410873			Assembly, Switch And Actuator
6	8519459			Clip, Toe Panel
7	8565054			Panel, Side
8	3392100	49621		Feet-Leveling
NI	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	49252			Plug, Multivalent
13	W10344192			Idler Assembly

14	279318		Terminal Tinned And Brass Panel
15	8564011		Bracket-Switch
16	W10167642		Cord, Power
NI	N/P	Not Available	(PARTS NOT SHOWN)
"	W10153836		10A Cord Lock
"	W10223804		10A Cord, Adapters
"	W10223809		10A Cord Adapters
"	W10223807		10A Cord Adapters
17	3393657		Restrainer, Belt
19	W10251066		Assembly, Door Switch
21	8066115	3394331	Plate Cover
22	8565083		Ramp, Door
23	8565122		Strike, Door
24	W10212660		Pad, Sound Dampening
25	W10225178		Base, Cabinet
26	W10225180		Panel, Rear
27	W10289662	W10416574	Motor-Drive
28	W10137398		Stop, Top Panel
29	W10167237		Pulley
30	W10131172		Belt, Drive
31	3397659		Block, Terminal
32	W10135695		Bracket, Motor
33	279393		Terminal Block Screw Kit
34	49026		4" - 90° Elbow
35	3977633		Autotransformer
36	8563747		Exhaust Pipe Medium Pipe
37	8563750		Exhaust Pipe
38	8563749		Exhaust Pipe
40	8540621		Panel, Toe
41	W10142290		Screw, 8-18 X 5/16
42	3400934		Assembly, Screw And Insulator
43	3390647	488729	Screw
44	3387242		Seal, Front Panel
45	3400000		Screw, 10-24 X 3/8
46	W10166301		Control Board
47	8563727		Bracket, Control
48	8565043		Plug, Strip Front Panel
49	3357011	308685	Side Trim)
50	W10255282		Front Panel
51	W10259136		Switch, Assembly
52	8318396		Foam-Seal
53	3391943		Boot, Foot
54	3405160		Belt, Drive
55	W10181903		Bracket, Burner
56	693995		Screw, Hex Head
57	W10096909		Burner Assembly 50 Hz
58	3393909		Screw, 8-32 X 7/8
59	343641	681414	Screw, 10AB X 1/2
60	3387057		Screw, 10-16 X 1/2 Orifice, Burner
61	686590	279311	Ignitor
62	8281918		Valve, Gas 60 Hz

63	3388235	Switch, Centrifugal
64	W10205520	Transformer, 120 To 22.5
65	W10237958	Transformer, 240 - 120
66	W10080820	Screw, 8-18 X .298
67	W10250903	Transformer Jumper
NI	279818	W10470674 Dryer Exhaust Kit

