



**NON – ILLUSTRATED  
PARTS**

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



Whirlpool Residential Whirlpool 3LCGD9100WQ1 Dryer Parts Parts Diagram 06 - OPTIONAL PARTS (NOT INCLUDED)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	8529894	<a href="#">346764</a>		Kit, Hold Down
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)

