


Whirlpool 3LCHW9100WQ0 04 - DISPENSER PARTS

DISPENSER PARTS

For Model: 3LCHW9100WQ0
(White)



W10299461

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

6

Whirlpool Residential Whirlpool 3LCHW9100WQ0 Washer Parts Parts Diagram 04 - DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10184482			Valve, Inlet
2	8540065			Hose, Valve To Dispenser
3	W10096852	596669		Clamp, Manifold
4	8540282	8181661		Screw, Actuator
5	8183181			Nozzle, Inlet
6	8540393			Cam, Actuator
7	8540394			Lever, Water Distribution
8	W10182763			Actuator
9	W10299421			Handle Assembly, Drawer
10	W10273032			Clamp, Hose
11	8540395			Connection, Lever
12	W10223702			Dispenser
13	8540053			Nozzle, Distribution
14	8540063			Hose, Dispenser To Tub
15	W10137456			Screw, 8-18 X 1/2
16	8540399			Cover, Detergent Drawer

17	8540402		Drawer, Detergent
18	W10137402	W10198458	Tab, Drawer Release
19	W10277537	W10433390	Dispenser
20	W10299438		Facia / Overlay, Drawer
21	W10137460		Cover, Handle
22	W10196695		Valve, Check
23	W10218846	W10196695	Valve, Check
24	W10276474		Door, Living Hinge

