


Whirlpool 3LWED5500YW0 01 - TOP AND CONSOLE PARTS



Whirlpool [Residential Whirlpool 3LWED5500YW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10454272		Not Available	INSTALLATION INSTRUCTIONS
"	W10454271		Not Available	GUIDE, USE & CARE
"	W10489084		Not Available	TECH SHEET
2	W10456268			Console Assembly
3	W10251392			Knob Assembly
4	W10362634			User Interface Assembly
5	W10323092			Seal, User Interface
6	W10274524			Tensioner, Facia
7	W10279552			Plug-Upper Rear Panel
8	W10219342			Screw, Baffle Mounting
9	W10096969			Panel, Rear Console
10	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	W10260246			Top
12	W10346523			CCU-Control
13	3390647	488729		Screw

14	8312709		Clip-Console
15	W10096918		Cover, Terminal Block
16	W10271580		Bracket, Motor Control
17	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
18	8536939		Clip, Knob
19	W10339708		Harness, Electric
20	W10123956		Dampening Panel
21	W10298336		8-18 Nch, U-Type NUT
22	W10280079		Seal, Console
23	W10325119		Spacer, Knob

