


Whirlpool 3LWED5500YW0 02 - CABINET PARTS



Whirlpool [Residential Whirlpool 3LWED5500YW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697773	3395530		Screw
2	693152			Bumper, Console
3	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	3397659			Block, Terminal
5	8318457			Switch, Broken Belt
6	690081	279570		Latch
7	8310656			Cabinet
8	3392100	49621		Feet-Leveling
NI	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	W10404617			Plug, Multivent
13	3388672	279640		Pulley-ldr
14	279218			Terminal Tinned And Brass

14	279910		Panel
15	488729		Screw
16	W10325058		Seal, Door
17	696144	279570	Latch
18	690997		Washer, Thrust
19	W10291934		Clip
20	W10121334		Washer, Thrust
21	3387560		Hinge, Door
"	3387559		Hinge, Door
22	3387565		Spring, Door
23	W10312811		Seal, Spill Guard
24	W10354249		Plate, Cover
25	8563747		Exhaust Pipe Medium Pipe
27	W10289661	W10416573	Motor-Drive
28	49026		4" - 90° Elbow
29	3402548		Pulley 50 Hz
30	3387610	661570	Belt
31	W10336128		Seal, Spill Guard
32	3387118		Bracket, Motor
33	279393		Terminal Block Screw Kit
34	W10237959		Door Switch Assembly
35	W10331278		Exhaust Pipe
36	3393008	308685	Side Trim)
37	8563749		Exhaust Pipe
38	343641	681414	Screw, 10AB X 1/2
39	W10118756		Idler Bracket
40	3357011	308685	Side Trim)
41	3387242		Seal, Front Panel
42	W10284093		Handle, Door
43	3388229		Retainer, Toe Panel
44	8066045		Door Inner
45	342055	488627	Screw
46	W10279553		Door, Front
47	697215	3406797	Toe Panel
48	697227	279659	Panel
49	W10083220		Lever, Snap Switch
50	3400934		Assembly, Screw And Insulator
51	W10236068		Bracket, Cabinet
52	W10186596	W10470674	Dryer Exhaust Kit

the laundry company®