


Whirlpool 3LWTW4740YQ0 02 - CONTROLS AND WATER INLET PARTS

CONTROLS AND WATER INLET PARTS

For Model: 3LWTW4740YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10496635

3

Whirlpool [Residential Whirlpool 3LWTW4740YQ0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND WATER INLET PARTS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|------------------------|---------------|---|
| 1 | W10365091 | | | Panel, Console |
| 2 | 8536939 | | | Clip, Knob |
| 3 | 8565957 | | | Cap, End |
| 4 | 8565954 | | | Cap, End |
| 5 | 8312709 | | | Clip-Console |
| 6 | W10480670 | | Not Available | CONTROL UNIT ASSEMBLY, MACHINE & MOTOR |
| 7 | W10420985 | | | Panel, Console Rear Cover |
| 8 | 1157158 | 489069 | | Xxscrew, 10-12 X 1/2 |
| 9 | W10268910 | | | Switch, Water Level |
| 10 | 90767 | | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 11 | W10446856 | | | Cord, Power |
| NI | N/P | | Not Available | (PARTS NOT SHOWN) |
| " | W10446855 | | | 10A Cord Lock |
| " | W10474959 | | | 10A Cord Adapters: |

| | | | |
|----|---------------------------|------------------------|--|
| " | W10476820 | | 10A Cord Adapters: |
| " | W10476822 | | 10A Cord Adapters: |
| 12 | 3400076 | | Screw, Bracket Mounting |
| 13 | W10034750 | | Timer Knob Assembly |
| 14 | W10034380 | | Knob, Control |
| 16 | W10291178 | | Harness, Upper |
| 17 | W10465928 | | Inlet Assembly, Water |
| 18 | W10465728 | Not Available | VALVE, WATER MIXING |
| 19 | W10441423 | | Vacuum Break |
| 20 | W10238347 | | Hose, Vacuum Break |
| 21 | W10117298 | 596669 | Clamp, Manifold |
| 22 | W10474662 | Not Available | HARNESSES, VALVE |
| 23 | 8281163 | | Screw, Dispenser Housing Mounting |
| 24 | 3400818 | | Screw, Timer Mounting |
| 25 | W10285511 | | Switch, Rotary Encoder |
| 26 | W10251309 | | Pushbutton, Start |
| 27 | W10242307 | 16123 | Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately. |
| 28 | 3949383 | | Hose, Water Inlet |
| " | 3949382 | | Hose, Water Inlet |
| 29 | W10434306 | | Filter, Line Assembly |
| 30 | W10269488 | | Connector- Hose, Y |
| 31 | 3357450 | | Washer, Water Inlet Hose |
| 32 | 3400073 | | Screw, Ground |

the laundry company[®]

the laundry company[®]