


Whirlpool 3LWTW4740YQ0 03 - BASKET AND TUB PARTS

BASKET AND TUB PARTS

For Model: 3LWTW4740YQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10496635

5

Whirlpool [Residential Whirlpool 3LWTW4740YQ0 Washer Parts](#) Parts Diagram 03 - BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3352483			Cap, Agitator
2	W10003790			Screw And Washer
3	3949550			Washer
4	63377			Agitator
5	W10215108			Ring, Tub
6	21366			Nut, Spanner
7	W10389330	W10349185		Basket
8	389140			Tub Block, Basket Drive
9	W10339098			Shield, Splash
10	W10238320	W10371566		Tub-Outer
11	W10006371	W10324647		Seal-Tub
12	W10215093			Filter, Drain Pump
13	8533928			Screw, 8-18 X 3/4
14	W10257088	W10349191		Suspension
15	W10405423	W10440729		Suspension
16	W10256551	W10440729		Suspension

17	W10422641		Harness, Lower
18	W10297436	353244	Hose, Pressure Switch
19	W10005430		Clamp, Pressure Hose Retainer
20	8533943	W10109200	Screw, Baffle Mounting
21	W10298887		Cable Tie
22	W10429200		Retainer, Push In

