


Whirlpool 3RAWZ480EMQ3 01 - TOP AND CONSOLE PARTS



1-07 Printed in U.S.A. (LT)

1

Part No. 8180750

Whirlpool [Residential Whirlpool 3RAWZ480EMQ3 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|---------------------------------|
| 1 | 8545902 | | Not Available | Label, Wiring Diagram |
| " | 8577079 | | Not Available | Use & Care Guide |
| " | 8563878 | | Not Available | Installation Instructions |
| " | 8315975 | | Not Available | Guide, User & Installation (UK) |
| 2 | 8519251 | W10117263 | | Top |
| 3 | 8543289 | W10110980 | | Harness, Main |
| 4 | 3979739 | W10118062 | | Panel, Console |
| 5 | 3394427 | | | Clip-Harness |
| 6 | 3980123 | W10118067 | | Bracket, Console |
| 7 | 353424 | | | Plug, Terminal |
| 8 | 94614 | | | Terminal |
| 9 | 3936144 | | | Do-It-Yourself Repair Manuals |
| 10 | 94613 | 596797 | | Terminal |
| 11 | 3390647 | 488729 | | Screw |
| 12 | 488886 | 488787 | | Screw |
| 13 | 3980121 | | | Button, Push-To-Start |

| | | | |
|----|-------------------------|---------------------------|--------------------------|
| 14 | 3979738 | W10118063 | Bracket, Timer |
| 15 | 3979743 | W10118064 | Bracket, Switch Mounting |
| 16 | 8281225 | | Screw, 8-18 X 1/2 |
| 17 | 8543319 | | Medallion |
| 18 | 3956540 | | Console, Center |
| 19 | 3400238 | | Screw, 2-28 X 1/2 |
| 20 | 3980205 | W10116280 | Timer |
| 21 | 3951198 | | Fuse |
| 22 | 3390646 | W10139210 | Screw, 8-18 X 5/16 |
| 23 | 3980421 | | Spacer Plate |
| 24 | 8316076 | W10168170 | Switch, Rotary |
| 25 | 8522378 | | Mini Buzzer |
| 26 | 8562100 | W10112668 | Switch, Push-To-Start |
| 27 | 3399642 | W10168169 | Switch, Wrinkle Guard |
| 28 | 8543291 | W10110978 | Harness, Console |
| 29 | 3347243 | | Block, Disconnect |
| 30 | 3397269 | | Connector, Timer |
| 31 | 3401144 | | Connector |
| 32 | 692997 | | Plug, Multi- Terminal |
| 33 | 3957756 | | Knob, Timer Assembly |
| 34 | 3957803 | | Knob, Control |
| 35 | 3980339 | | Shield, Drip |
| 36 | 688805 | | Clip, Spring Knob |

