


Whirlpool 3RAWZ480ESQ0 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

DOOR PARTS
For Model: 3RAWZ480ESQ0
(White)



W10129423

7

Whirlpool [Residential Whirlpool 3RAWZ480ESQ0 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8563855			Label, Hinge Hole
2	W10111142	280201		Hinge
3	3980214			Cover, Door Hinge
4	W10080840			Screw, 8-18 X 5/8
5	342043	486146		Screw
7	8559752			Handle, Door
8	W10080770		Not Available	Screw, 1/4-20 x 1/2
9	8519374			Plug, Door Handle
10	W10118207			Door Assembly
11	355515			Screw, 8-18 X 11/16
12	3980213			Door, Outer
13	8545879	8545878		Window
14	3389441			Door Catch Assembly
15	690081	279570		Latch
	72017			Paint, Touch-Up

"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down

