


Whirlpool 3RAWZ481EML3 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

DOOR PARTS
For Model: 3RAWZ481EML3
(Pewter)



8180751

7

Whirlpool [Residential Whirlpool 3RAWZ481EML3 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8563855			Label, Hinge Hole
2	8565678	280201		Hinge
3	3980214			Cover, Door Hinge
4	9742177			Screw, 8-18 X .625
5	342043	486146		Screw
7	8559752			Handle, Door
8	3400224			Screw, 1/4-20 X 3/8
9	8519374			Plug, Door Handle
10	8557500			Door Assembly
11	355515			Screw, 8-18 X 11/16
12	3980213			Door, Outer
13	8545879	8545878		Window
14	3389441			Door Catch Assembly
	4396174			Paint, Touch-Up
"	4396175			Paint, Pressurized Spray

"	350938		Paint, Pressurized Spray B
"	BLANK	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down

