


# Whirlpool 3RAWZ481GML0 02 - CABINET PARTS



8180079

3

Whirlpool [Residential Whirlpool 3RAWZ481GML0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8317342	<a href="#">W10119283</a>		Cover, Terminal Block
2	98139	<a href="#">303776</a>		Screw
3	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
4	8519217	<a href="#">3980359</a>		Panel
5	<a href="#">8318457</a>			Switch, Broken Belt
6	8521947	<a href="#">W10139360A</a>		Rack-Dry
7	8519216	<a href="#">3980358</a>		Panel
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">3979261</a>			Plug, Multivent
13	3388672	<a href="#">279640</a>		Pulley-ldr
14	<a href="#">3978776</a>			Bracket, Gas Pipe Switch
15	<a href="#">8066120</a>			Lever, Door Switch

16	<a href="#">3394081</a>		Wire, Broken Belt Switch
17	8528076	<a href="#">8564134</a>	Board, Sound Dampening
18	<a href="#">233520</a>		Washer, Thrust
19	<a href="#">8543119</a>		Jumper, Door Switch
20	<a href="#">690997</a>		Washer, Thrust
21	8066115	<a href="#">3394331</a>	Plate Cover
22	<a href="#">8529053</a>		Ramp, Door Door Switch
23	<a href="#">8521961</a>		Support, Dry Rack
24	<a href="#">8541503</a>		Kit, Stack Assembly
25	8521950	<a href="#">W10139360A</a>	Rack-Dry
26	<a href="#">3393657</a>		Restrainer, Belt
27	3404470	<a href="#">W10416573</a>	Motor-Drve
28	<a href="#">3397659</a>		Block, Terminal
29	<a href="#">3402548</a>		Pulley 50 Hz
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">8529757</a>		Bracket, Burner
32	<a href="#">3387118</a>		Bracket, Motor
33	<a href="#">3977712</a>		Cord, Power
34	<a href="#">49026</a>		4" - 90° Elbow
35	<a href="#">693995</a>		Screw, Hex Head
36	<a href="#">3395532</a>		Exhaust Pipe And Bracket
37	<a href="#">3395534</a>		Exhaust Pipe
38	3395535	<a href="#">8563749</a>	Exhaust Pipe
39	3388674	<a href="#">W10118756</a>	Idler Bracket
41	<a href="#">8541808</a>		Switch, Door
42	<a href="#">3400934</a>		Assembly, Screw And Insulator
43	3390647	<a href="#">488729</a>	Screw
44	<a href="#">3387242</a>		Seal, Front Panel
45	3393008	<a href="#">308685</a>	Side Trim )
46	<a href="#">8519459</a>		Clip, Toe Panel
47	<a href="#">694415</a>		Clip, Strain Relief
48	<a href="#">3977633</a>		Autotransformer
49	340025	<a href="#">687133</a>	Wire
50	<a href="#">8519207</a>		Base, Cabinet
51	8543083	<a href="#">280092</a>	Panel
52	696144	<a href="#">279570</a>	Latch
53	<a href="#">8316063</a>		Adapter, Gas Inlet
56	8519273	<a href="#">W10119274</a>	Bracket, Control
61	<a href="#">3980095</a>		Toe, Panel
62	8543118	<a href="#">280037</a>	Panel-Rear
63	<a href="#">692400</a>		Nut, Push-In
64	<a href="#">3400097</a>		Screw, 10-24 X 3/8
"	BLANK	Not Available	Optional Parts Not Included
66	279969	<a href="#">W10470674</a>	Dryer Exhaust Kit