


Whirlpool 3RGSC9400RL0 01 - TOP AND CABINET PARTS



12-05 Litho in U.S.A. (dtd)

1

Part No. 6180799

Whirlpool [Residential Whirlpool 3RGSC9400RL0 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8318424		Not Available	Installation Instructions
"	8315977		Not Available	Use & Care Guide
"	3954736		Not Available	Wiring Diagram
"	8315975		Not Available	Guide, User & Installation (UK)
2	3957075			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	3956112			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	8566266			Dispenser, Bleach
8	3351614			Screw, Gearcase Cover Mounting
9	3357011	308685		Side Trim)
10	3976348			Absorber, Sound
11	8318084			Switch, Lid
12	21097			Pad, Lid Hinge

13	355274	W10119828	Screw, Lid Hinge Mounting
14	3957287		Handle, Lid
15	8559336	W10225136	Hinge 7 Pad Assembly
16	91770		Hinge, Lid
17	3957286	Not Available	Insert, Handle
18	8319539		Bearing, Lid Hinge
19	8577123	3957602	Lid
20	9724509		Bumper, Lid
21	3390631		Screw, 10-16 X 3/8

