


Whirlpool 3RGSC9400SL1 05 - MACHINE BASE PARTS

MACHINE BASE PARTS

For Model: 3RGSC9400SL1
(Pewter)



8

W10218842

Whirlpool Residential Whirlpool 3RGSC9400SL1 Washer Parts Parts Diagram 05 - MACHINE BASE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10080750			Screw, Bracket Mounting
2	64067			Bracket, Spring Outer
3	63907			Spring, Suspension
4	W10117005			Support And Brake, Tub
5	64065			Bracket, Spring Outer
6	63466			Link, Leveling Mechanism
7	62597	8316845		Spring
8	W10080920			Pin, Knurled
9	W10083250	W10133065		Feet-Leveling
10	8546455			Bearing, Centerpost
11	357409	359449		Seal, Agitator Shaft
12	388492	W10250667		Spring, Counterweight
13	62568	285219		Pad
14	3946509			Plate, Suspension
15	3363660	285744		Pad
16	W10116943			Base Assembly

17	W10080250	Nut, Lock
18	W10080910	Foot, Front
19	8577376	Seal, Centerpost
20	285203	Centerpost Bearing Kit
21	63134	Ring, Sound Deadening
22	W10145155	Retainer, Suspension Spring
23	8544816	Absorber, Sound

