


# Whirlpool 3RLSQ8033RW2 01 - TOP AND CABINET PARTS



4-06 Litho in U.S.A. (drd)

1

Part No. 8180802

Whirlpool [Residential Whirlpool 3RLSQ8033RW2 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8316566		Not Available	Installation Instructions
"	8558611		Not Available	Use & Care Guide
"	3954738		Not Available	Wiring Diagram
"	8315975		Not Available	Guide, User & Installation (UK)
2	<a href="#">8318064</a>			Top
3	62750			Spacer, Cabinet To Top (4)
4	<a href="#">357213</a>			Nut, Push-In
5	<a href="#">63424</a>			Cabinet
6	<a href="#">62780</a>			Clip, Top And Cabinet And Rear Panel
7	<a href="#">3362952</a>			Dispenser, Bleach
8	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting
9	3357011	<a href="#">308685</a>		Side Trim )
10	<a href="#">3976348</a>			Absorber, Sound
11	<a href="#">8318084</a>			Switch, Lid
12	8533959	<a href="#">680762</a>		Nut

13	3351355	<a href="#">W10119828</a>	Screw, Lid Hinge Mounting
15	<a href="#">8318088</a>		Hinge, Lid
16	<a href="#">54583</a>		Hinge, Lid
17	<a href="#">19119</a>		Bumper, Lid Hinge
18	<a href="#">21258</a>		Bearing, Lid Hinge
19	8541743	<a href="#">3957510</a>	Lid
22	<a href="#">9724509</a>		Bumper, Lid
28	<a href="#">3390631</a>		Screw, 10-16 X 3/8

