


**Whirlpool 3RLSQ8033RW2 08 - GEARCASE PARTS, OPTIONAL PARTS
(NOT INCLUDED)**



12

8180802

Whirlpool Residential Whirlpool 3RLSQ8033RW2 Washer Parts Parts Diagram 08 - GEARCASE PARTS, OPTIONAL PARTS (NOT INCLUDED)

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3949118	3363395		Gearcase
2	285202			Cover, Gearcase
3	3349985			Seal, Gearcase Cover
4	285195			Sealer Sealer, Gasket
5	63320	285362		Gear and Pinion
6	356427			Seal, Spin Pinion
7	389387			Shaft, Agitator
8	90369		Not Available	Ring, Retaining (2)
9	62677			Retainer, Spring
10	62676			Spring, Agitator
11	63273	285509		Shaft, Agitator
12	62619			Washer, Agitator Gear
13	62580	285206		Cam-Agitator
14	62581	285206		Cam-Agitator
15	285509			Shaft, Agitator

16	62618		Washer, Cam Thrust
17	16018	285205	Bearing
18	85529	285205	Bearing
19	3366851	3363395	Gearcase
21	285352		Seal Kit, Thrust Plug
22	3351614		Screw, Gearcase Cover Mounting
23	3362552	285765	Ring-Retrn
24	285735	285766	Washer Kit, Thrust
25	3348567	W10233584	Gear-Spin
26	285595		Neutral Assembly
27	3349296	8546456	Rack, Connecting
28	62621		Actuator, Shift
29	388815		Washer, Intermediate 1 3976263 Miscellaneous Parts Bag 2 3976300 Washer, Inlet Hose 3 3366913 Clamp, Hose
	72017		Paint, Touch-Up
"	350938		Paint, Pressurized Spray B
"	350930		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)
"	BLANK	Not Available	OIL
"	350572		Oil
"	BLANK	Not Available	LUBRICANT
"	285208		Lubricant
"	BLANK	Not Available	SEALER
"	285195		Sealer Sealer, Gasket
"	BLANK	Not Available	ACCESSORY PARTS
"	367031		Water System Parts
"	280129	280129A	Break-Sphn
"	280130	280130A	Adapter
"	280131	40922	Hose

