


Whirlpool 3RLSQ8033SW1 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 3RLSQ8033SW1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3349365			Hose, Sensor
2	8317975			Restraint, Harness
3	3949382			Hose, Water Inlet
"	3949383			Hose, Water Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	W10096921			Drain Hose Assembly
9	W10222216			Timer, Control
10	W10242307	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
11	W10080280			Screw, 8-18 X 3/8
12	W10213199	W10339334		Switch-WL
13	8544893			Bracket, Control

14	W10111552		Cord, Power
15	8559337	285777	Relief-Str
16	8541780	285980	Endcap
17	W10080580		Screw, Gearcase Cover Mounting
18	3360397		Valve, Water Mixing
19	W10111181		Fuse
20	8536939		Clip, Knob
21	W10117299	596669	Clamp, Manifold
22	3357319		Hose, Vacuum Break
23	W10117298	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	W10217035		Harness, Wiring
26	8314879		Shield, Inlet Valve
27	8541667		Clamp, Hose
28	8541668		Clamp, Hose
29	3352282		Sensor-Etc-Inline
30	W10094820	616099	Clamp
31	W10112110	285655	Clamp, Hose
32	W10116973	285871	Hose
33	8316039		Shield, Atc
34	W10110247		Control, Atc-lec
35	W10168262		Switch, Rotary
36	3400818		Screw, Timer Mounting
37	W10130933		Screw, Ground
38	3407160		Transformer
39	W10115456		Panel, Console
40	8055003		Clip, Harness And Pressure Switch
41	W10113937		Clip, Grounding
42	W10110977		Wire, Ground
43	8519200		Support, Rear Panel
44	8544945		Knob, Timer
45	8544947		Dial, Timer
46	8544937		Knob, Control
47	3347868	W10339879	Tie, Cable
48	3352944		Clip, Harness
49	W10080350		Screw, 8-18 X 1.25
50	W10080260		Screw, 10-16 X 5/16
51	8541779	285980	Endcap
52	W10168171		Switch, Rotary
53	3357397		Adapter, Water Inlet Hose

the laundry company[®]