


Whirlpool 3RLSQ8033SW1 04 - BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: 3RLSQ8033SW1
(White/Grey)



W10218841

7

Whirlpool [Residential Whirlpool 3RLSQ8033SW1 Washer Parts](#) Parts Diagram 04 - BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10117003			Brake And Drive Tube
2	63292			Washer, Spin Tube Thrust
3	W10080230			Ring, Spin Tube Support
4	63283	285353		Ring
5	W10116968			Clutch
6	W10118761			Band And Lining, Clutch
7	62646			Cap, Clutch Spring
8	3946792			Spring And Damper Assembly
9	W10116916	W10140308		Gearcase
10	W10080600	W10080610		Screw
11	62611			Plate, Motor Mount To Gearcase
12	62691			Grommet, Motor
13	3364003	285753A		Coupling
14	8577374			Seal, Centerpost

15	3355454		Clip, Main Drive
16	W10080610		Screw
17	W10086010		Retainer, Motor
18	3362089		Shield, Tub To Motor
19	3950297		Motor, Main Drive
20	8529896		Switch, Main Drive Motor
21	8546127		Retainer, Pump
22	3363394		Pump
23	W10080650	273556	Screw, 10-16 X 5/8
24	8316060		Shield, Tub To Motor
25	W10080260		Screw, 10-16 X 5/16
26	8572719	482156	Capacitor
27	W10083210		Clamp, Capacitor

the laundry company[®]

the laundry company[®]

the laundry company[®]