


# Whirlpool 3RLSQ8033SW1 07 - BRAKE AND DRIVE TUBE PARTS

## BRAKE AND DRIVE TUBE PARTS

For Model: 3RLSQ8033SW1  
(White/Grey)



W10218841

11

Whirlpool Residential Whirlpool 3RLSQ8033SW1 Washer Parts Parts Diagram 07 - BRAKE AND DRIVE TUBE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10117003</a>			Brake And Drive Tube
2	<a href="#">62658</a>			Ring, Thrust
3	<a href="#">356427</a>			Seal, Spin Pinion
4	<a href="#">W10117001</a>			Tube, Basket Drive
5	<a href="#">W10083190</a>			Ring, Retaining
6	W10116995	<a href="#">285438</a>		Shoe-Brake
7	<a href="#">8546462</a>			"T" Bearing, Spin Tube
8	3353956	<a href="#">285658</a>		Sleeve
9	387806		Not Available	Spring, Brake
10	3355360	<a href="#">285658</a>		Sleeve
11	<a href="#">8546461</a>			Cam, Brake Release
12	<a href="#">63022</a>			Sleeve, Cam
13	64194	<a href="#">285790</a>		Lining
14	<a href="#">W10083200</a>			Ring, Retaining
	BLANK		Not Available	Following Parts Not Illustrated
"	<a href="#">285208</a>			Lubricant