


Whirlpool 3XGSC9455JQ4 01 - TOP AND CABINET PARTS



8-05 Litho in U.S.A. (awm)

1

Part No. 8180739

Whirlpool [Residential Whirlpool 3XGSC9455JQ4 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8318353		Not Available	Installation Instructions
"	8316483		Not Available	Use & Care Guide
"	3954736		Not Available	Wiring Diagram
2	8318064			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3362952			Dispenser, Bleach
8	3351614			Screw, Gearcase Cover Mounting
9	3357011	308685		Side Trim)
10	3976348			Absorber, Sound
11	8318084			Switch, Lid
12	8533959	680762		Nut
13	3351355	W10119828		Screw, Lid Hinge Mounting

15	8318088		Hinge, Lid
16	54583		Hinge, Lid
17	19119		Bumper, Lid Hinge
18	21258		Bearing, Lid Hinge
19	8541743	3957510	Lid
22	9724509		Bumper, Lid
28	3390631		Screw, 10-16 X 3/8

