


Whirlpool 3XGSC9455JQ6 01 - TOP AND CABINET PARTS



4-06 Litho in U.S.A. (drd)

1

Part No. 8181166

Whirlpool [Residential Whirlpool 3XGSC9455JQ6 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10131576		Not Available	Installation Instructions
"	W10131572		Not Available	Use & Care Guide
"	3954736		Not Available	Wiring Diagram
2	8318064			Top
3	62750			Spacer, Cabinet To Top (4)
4	357213			Nut, Push-In
5	63424			Cabinet
6	62780			Clip, Top And Cabinet And Rear Panel
7	3362952			Dispenser, Bleach
8	3351614			Screw, Gearcase Cover Mounting
9	3357011	308685		Side Trim)
10	3976348			Absorber, Sound
11	8318084			Switch, Lid
12	8533959	680762		Nut
13	3351355	W10119828		Screw, Lid Hinge Mounting

15	8318088	Hinge, Lid
16	54583	Hinge, Lid
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge
19	8541743	3957510 Lid
20	9724509	Bumper, Lid
21	3390631	Screw, 10-16 X 3/8

