


Whirlpool 3XLBR5432JQ3 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 3XLBR5432JQ3 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
2	3398893	3395559		Wire
3	3949382			Hose, Water Inlet
"	3949383			Hose, Water Inlet
4	3357027			Nozzle, Hose Drain
5	8568314			Strap, Console
6	8318407			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3954786			Timer, Control
10	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366849	W10339228		Switch-WL

13	3948814		Bracket, Control
14	8316045		Cord, Power
15	3949468	285777	Relief-Str
16	8271369	279962	Endcap
17	3351614		Screw, Gearcase Cover Mounting
18	3360397		Valve, Water Mixing
19	3976395		Restraint, Hose
20	2219077		Clip, Pressure Switch Hose
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	303294	3367669	Protector, Edge
26	8317940	W10358149	Drain Hose Assembly
27	356138		Clamp, Hose
28	3951198		Fuse
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
36	3400818		Screw, Timer Mounting
37	3179795		Screw, Ground
39	8318779		Panel, Console
41	357572	W10113937	Clip, Grounding
44	8271345	3957824	Knob, Timer
45	8271351	3957849	Dial, Timer
47	8271339	3957799	Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271363	279962	Endcap
55	3366913	3357331	Clamp, Drain
58	8314879		Shield, Inlet Valve
59	3950829	3976286	Shield, Capacitor
60	3956874		Harness, Wiring

