


Whirlpool 3XLR5432JQ5 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 3XLR5432JQ5
(Designer White)



8181144

5

Whirlpool Residential Whirlpool 3XLR5432JQ5 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3355758			Cap, Agitator
2	358237			Screw And Washer
3	3949550			Washer
4	3350830			Agitator
5	3950568			Tub Ring And Gasket
6	3359586			Gasket, Tub Ring
7	8519815			Clip, Balance Ring
8	3956205			Balance Ring
9	21366			Nut, Spanner
10	3956206	3956207		Basket And Balance Ring
11	63125			Tub
12	389140			Tub Block, Basket Drive
13	383727			Gasket, Centerpod
14	3363657	353244		Hose, Pressure Switch
15	2219077			Clip, Pressure Switch Hose
16	3363663	285811		Cam-Agitator

17	3366877	80040	Dog-Agitator
18	3363661		Bearing, Driven Cam
19	3350389	285587	Washer
20	3349019		Auger, Agitator
21	3354733	W10074580	Cap, Barrier
22	3348855	W10072840	Fabric Softener
23	3350829	285574	Large Ring

