


Whirlpool 3XLBR8543JQ1 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 3XLBR8543JQ1 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	3949180	W10168257		Switch, Rotary
2	3398893	3395559		Wire
3	3949382			Hose, Water Inlet
"	3949383			Hose, Water Inlet
4	3357027			Nozzle, Hose Drain
5	8318255	8568314		Strap, Console
6	8318407			Panel, Rear
7	62747			Pad, Rear Panel
8	3951609	285664		Hose
"	661577	285666		Hose
"	3357090	285702		Hose
9	3954730			Timer, Control
10	285750		Not Available	(Kit-Adapter) (Includes. Item) (20. And 27.)
11	90767			Screw, 8A X 3/8 Hex Washer Head Tapping

12	3366848	W10339229	Switch-WL
13	3948814		Bracket, Control
14	8316045		Cord, Power
15	3949468	285777	Relief-Str
16	8271369	279962	Endcap
17	3351614		Screw, Gearcase Cover Mounting
18	3360397		Valve, Water Mixing
19	3976395		Restraint, Hose
20	3363920	3363920A	Adapter
21	370451	596669	Clamp, Manifold
22	62662	3357328	Hose, Vacuum Break
23	371503	596669	Clamp, Manifold
24	3347034		Break, Vacuum
25	303294	3367669	Protector, Edge
26	8317940	W10358149	Drain Hose Assembly
27	356138		Clamp, Hose
28	3951198		Fuse
29	3952439		Buzzer, Mini
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
35	661614		Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	3179795		Screw, Ground
39	8318783		Panel, Console
41	357572	W10113937	Clip, Grounding
44	8271345	3957824	Knob, Timer
45	8271351	3957849	Dial, Timer
47	8271339	3957799	Knob, Control
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271363	279962	Endcap
55	3366913	3357331	Clamp, Drain
58	8314879		Shield, Inlet Valve
59	3950829	3976286	Shield, Capacitor
60	3956190		Harness, Wiring
"	N/A		Not Available
"	3357397		FOLLOWING PARTS NOT ILLUSTRATED Adapter, Water Inlet Hose
"	3976290	3357450	Washer, Water Inlet Hose