


Whirlpool 3XLB8543JQ3 03 - AGITATOR, BASKET AND TUB PARTS

AGITATOR, BASKET AND TUB PARTS

For Model: 3XLB8543JQ3
(Designer White)



8180783

5

Whirlpool [Residential Whirlpool 3XLB8543JQ3 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	63580			Dispenser, Fabric Softener
2	358237			Screw And Washer
3	3354845			Clip, Agitator
4	3350830			Agitator
5	3950568			Tub Ring And Gasket
6	3359586			Gasket, Tub Ring
7	8519815			Clip, Balance Ring
8	3956205			Balance Ring
9	2219077			Clip, Pressure Switch Hose
10	8543666			Washer, Agitator
11	3363661			Bearing, Driven Cam
12	21366			Nut, Spanner
13	3956206	3956207		Basket And Balance Ring
14	63125			Tub
15	389140			Tub Block, Basket Drive
16	383727			Gasket, Centerpod

17	3363657	353244	Hose, Pressure Switch
19	3363663	285811	Cam-Agitator
20	3366877	80040	Dog-Agitator
22	3350389	285587	Washer
23	3354733	W10074580	Cap, Barrier
24	3348855	W10072840	Fabric Softener
26	3949550		Washer
27	3350829	285574	Large Ring
28	3349019		Auger, Agitator

