


# Whirlpool 3XLER5435HQ2 02 - CABINET PARTS



8180227

3

Whirlpool [Residential Whirlpool 3XLER5435HQ2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">693995</a>			Screw, Hex Head
4	3393008	<a href="#">308685</a>		Side Trim )
5	<a href="#">3396795</a>			Cover, Terminal Block
6	<a href="#">3403630</a>			Plug, Strike Hole
7	3396805	<a href="#">280043</a>		Panel-Rear
8	<a href="#">3394926</a>			Screw, 10-16 X 1/2
9	<a href="#">8541400</a>			Bracket, Cabinet
10	3406109	<a href="#">3406107</a>		Door Switch Assembly
11	697773	<a href="#">3395530</a>		Screw
12	<a href="#">3404413</a>			Plug, Hinge Hole
15	<a href="#">3394083</a>			Clip, Front Panel
16	3392100	<a href="#">49621</a>		Feet-Leveling
18	8530603	<a href="#">8533643</a>		Cabinet
19	<a href="#">98234</a>			Clip, U-Bend
20	690363	<a href="#">18776</a>		Lock, Front Top

21	3403444	<a href="#">279852</a>	Panel
23	685203	<a href="#">279220</a>	Clip
24	690081	<a href="#">279570</a>	Latch
27	342055	<a href="#">488627</a>	Screw
28	3405514	<a href="#">W10362431</a>	Hinge And Pin Assembly
29	<a href="#">279318</a>		Terminal Tinned And Brass Panel
33	<a href="#">3403431</a>		Strike, Panel
35	<a href="#">3402341</a>		Door, Inner
36	<a href="#">3402335</a>		Door, Front
37	<a href="#">3405184</a>		Handle, Door
38	<a href="#">3406129</a>		Seal And Bearing Assembly
39	<a href="#">694415</a>		Clip, Strain Relief
41	<a href="#">3397659</a>		Block, Terminal
42	<a href="#">279393</a>		Terminal Block Screw Kit
45	3387258	<a href="#">W10111542</a>	Cord, Power
46	238088	<a href="#">8066217</a>	Hinge, Top
47	690046		Not Available
48	<a href="#">691366</a>		SCREW, SET 1/4 - 28 X 3/8
49	8066065	<a href="#">341241</a>	Idler And Pulley Assembly
50	<a href="#">348780</a>		Belt
51	<a href="#">3400500</a>		Base, Motor
52	<a href="#">685064</a>		Bolt, 3405245 5/16-18 X 3/4
53	<a href="#">3404162</a>		Pulley, 50 Hz
54	<a href="#">3388235</a>		Clamp, Motor
55	685815	<a href="#">W10416572</a>	Switch, Centrifugal
56	<a href="#">660658</a>		Motor-Drve
57	<a href="#">690236</a>		Clamp, Motor Mounting 343481 685441
58	<a href="#">3405246</a>		Wire, Ground
59	697776	<a href="#">4331106</a>	Seal, Door Push-To-Start
			Screw, No.10-32 X 7/16

