


Whirlpool 3XLSQ7533JQ5 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 3XLSQ7533JQ5 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8541669			Bucket, Drain Hose
2	8541658			Bucket, Drain Hose
3	3949382			Hose, Water Inlet
"	3949383			Hose, Water Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	8559373	W10096921		Drain Hose Assembly
9	3954730			Timer, Control
10	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	3366848	W10339229		Switch-WL
13	3948608			Bracket, Control

14	8559411	W10111545	Cord, Power
15	8559337	285777	Relief-Str
16	8271369	279962	Endcap
17	3351614		Screw, Gearcase Cover Mounting
18	3360397		Valve, Water Mixing
19	3347868	W10339879	Tie, Cable
20	8317975		Restraint, Harness
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	3952439		Buzzer, Mini
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	W10111181		Fuse
29	3352944		Clip, Harness
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
34	8541668		Clamp, Hose
35	661612	W10168256	Switch, Water Temperature
36	3400818		Screw, Timer Mounting
37	3179795		Screw, Ground
38	8536939		Clip, Knob
39	8318780		Panel, Console
40	8055003		Clip, Harness And Pressure Switch
41	357572	W10113937	Clip, Grounding
42	3398893	3395559	Wire
44	3957824		Knob, Timer
45	3957849		Dial, Timer
46	3957799		Knob, Control
47	3357397		Adapter, Water Inlet Hose
49	388326		Screw, 8-18 X 1.25
50	62863	3390631	Screw, 10-16 X 3/8
51	8271363	279962	Endcap
52	3949180	W10168257	Switch, Rotary
53	8314879		Shield, Inlet Valve
54	3956871		Harness, Wiring

the laundry company[®]