


Whirlpool 3XWED5705SW3 01 - TOP AND CONSOLE PARTS



11-11 Litho in U.S.A. (BMN)(bay)

1

Part No. W10458948 Rev. A

Whirlpool Residential Whirlpool 3XWED5705SW3 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10396186		Not Available	WIRING DIAGRAM
"	W10131645		Not Available	Guide, Use & Care
"	W10115524		Not Available	Instructions, Installation
2	8317305	285909		Panel-Rear
3	8299769	W10116281		Timer
4	W10238464			Switch, Push-To-Start
5	8533951	3400859		Screw, Grounding
6	W10096918			Cover, Terminal Block
7	8271363	279962		Endcap
8	8544897			Bracket, Control
9	8533951	3400859		Screw, Grounding
10	8536939			Clip, Knob
11	388326			Screw, 8-18 X 1.25
12	W10168170			Switch, Rotary
13	W10034380			Knob, Control
14	3955775	8303811		Badge, Assembly

15	W10168168		Switch, Rotary
16	W10386319		Harness, Wiring
17	W10034750		Timer Knob Assembly
18	W10034790		Knob, Push-To-Start
19	8318255	8568314	Strap, Console
20	357213		Nut, Push-In
21	8271399	3979278	Top
22	8522378		Mini Buzzer
23	8271369	279962	Endcap
24	W10128691		Wire, Jumper
25	W10095950		Panel, Control
26	W10128690		Wire, Jumper Assembly
27	W10110977		Wire, Ground
28	3390647	488729	Screw
29	98139	303776	Screw
30	W10113937		Clip, Grounding

