


Whirlpool 3XWGD5705SW2 04 - W10096909 BURNER ASSEMBLY,
OPTIONAL PARTS (NOT INCLUDED)

W10096909 BURNER ASSEMBLY

For Model: 3XWGD5705SW2
(Designer White)



W10247722

7

Whirlpool [Residential Whirlpool 3XWGD5705SW2 Dryer Parts](#) Parts Diagram 04 - W10096909 BURNER ASSEMBLY,
OPTIONAL PARTS (NOT INCLUDED)
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096909			Burner Assembly 50 Hz
2	688617	693140		Burner
3	694298			Bracket, Ignitor
4	686590	279311		Ignitor
5	W10080730	3393909		Screw, 8-32 X 7/8
6	W10080580			Screw, Gearcase Cover Mounting
7	3389871		Not Available	Base, Burner
8	W10080630	3387057		Screw, 10-16 X 1/2 Orifice, Burner
9	234660			Orifice, Burner Type 1
10	8281918			Valve, Gas 60 Hz
11	694421			Screw, Bracket Mounting
12	694538			Bracket, Shunt
13	695297	307930		Coil, Secondary

14	695298	Y307931	Coil, Holding And Booster
15	694424		Leak, Limiter
16	694423		Screw, Regulator Adjustment
17	694422		Spring, Regulator
20	239822	W10295523	Plug, Pipe
21	W10097610		Pipe, Gas Supply
22	697441		Valve And Union Shut-Off
23	3393767		Pipe, Tail
24	233076		Nut, Compression
25	3387561		Clamp-Pipe
26	3389889		Bracket, Support
27	W10080320		Screw, 10-16 X 1/2
	BLANK	Not Available	Following Parts Not Illustrated
"	W10135245	W10402145	LP Gas Con
"	BLANK	Not Available	ACCESSORY PARTS
"	3406911	8212450A	Dryer Rack
"	4392067		Kit, Dryer Repair
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

