


Whirlpool 3XWTW5905SW0 02 - CONTROLS AND REAR PANEL PARTS



Whirlpool [Residential Whirlpool 3XWTW5905SW0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND REAR PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8541669			Bucket, Drain Hose
2	8541658			Bucket, Drain Hose
3	3949382			Hose, Water Inlet
"	3949383			Hose, Water Inlet
4	8577378			U-Bend, Drain Hose
5	8568314			Strap, Console
6	8318015			Panel, Rear
7	62747			Pad, Rear Panel
8	W10127860	W10096921		Drain Hose Assembly
9	W10106010	W10222216		Timer, Control
10	3976300	16123		Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
11	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
12	8577842	W10339250		Switch-WL
13	3950194			Bracket, Control

14	W10111545		Cord, Power
15	8559337	285777	Relief-Str
16	8271369	279962	Endcap
17	3351614		Screw, Gearcase Cover Mounting
18	3360397		Valve, Water Mixing
19	3347868	W10339879	Tie, Cable
20	8271363	279962	Endcap
21	301958	596669	Clamp, Manifold
22	8541607	3357328	Hose, Vacuum Break
23	370450	596669	Clamp, Manifold
24	387606	3360977	Break-Vac
25	3952439		Buzzer, Mini
26	8519200		Support, Rear Panel
27	8541667		Clamp, Hose
28	8541668		Clamp, Hose
29	3352944		Clip, Harness
30	3363366	616099	Clamp
31	8317496	285655	Clamp, Hose
32	3951449	285871	Hose
33	3400818		Screw, Timer Mounting
34	3400073		Screw, Ground
35	8536939		Clip, Knob
36	W10095570		Panel, Console
37	8055003		Clip, Harness And Pressure Switch
38	357572	W10113937	Clip, Grounding
39	3398893	3395559	Wire
40	W10034730		Knob, Timer
41	8566018		Dial,
42	W10034380		Knob, Control
43	3357397		Adapter, Water Inlet Hose
44	388326		Screw, 8-18 X 1.25
45	62863	3390631	Screw, 10-16 X 3/8
46	8314879		Shield, Inlet Valve
47	3951198		Fuse
48	W10111598		Harness, Wiring
49	W10096869		Switch, Clean Touch

the laundry company[®]