


Whirlpool 4GNED4600YQ0 01 - CABINET PARTS



3-12 Litho in U.S.A. (BMN)(bay) 1 Part No. W10494722 Rev. A

Whirlpool [Residential Whirlpool 4GNED4600YQ0 Dryer Parts](#) Parts Diagram 01 - CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10454274		Not Available	INSTRUCTIONS, INSTALLATION
"	W10462985		Not Available	USE & CARE GUIDE
"	W10396180		Not Available	WIRING DIAGRAM
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	W10236073			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	3403630			Plug, Strike Hole
7	3396805	280043		Panel-Rear
8	3393008	308685		Side Trim)
9	3405246			Seal, Door Push-To-Start
10	3406109	3406107		Door Switch Assembly
11	697773	3395530		Screw
12	3404162			Clamp, Motor
13	343641	681414		Screw, 10AB X 1/2
14	3404413			Plug, Hinge Hole

15	3394083		Clip, Front Panel
16	3392100	49621	Feet-Leveling
NI	279810		Foot-Optional
17	279318		Terminal Tinned And Brass Panel
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	8066092		Lock, Front Top
21	W10224853		Front Panel Assembly
22	W10121316		Plug, Multivent
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	W10289660	W10416572	Motor-Drve
26	8066217		Hinge, Top
27	342055	488627	Screw
28	W10362431		Hinge And Pin Assembly
29	690046	Not Available	SCREW, SET 1/4 - 28 X 3/8
30	3400500		Bolt, 3405245 5/16-18 X 3/4
31	348780		Base, Motor
32	W10131364	341241	Belt
33	3403431		Strike, Panel
34	691366		Idler And Pulley Assembly
35	3402341		Door, Inner
36	3402335		Door, Front
37	8559779		Handle, Door
38	3406129		Seal And Bearing Assembly
39	279393		Terminal Block Screw Kit
40	3390631		Screw, 10-16 X 3/8
41	3397659		Block, Terminal
42	685011		Pulley, 60 Hz

