


Whirlpool 4GWED4900YW0 01 - CABINET PARTS



Whirlpool [Residential Whirlpool 4GWED4900YW0 Dryer Parts](#) Parts Diagram 01 - CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10454274		Not Available	INSTRUCTIONS, INSTALLATION
"	W10454275		Not Available	USE & CARE GUIDE
"	8578889		Not Available	Wiring Diagram
2	343641	681414		Screw, 10AB X 1/2
3	693995			Screw, Hex Head
4	W10236073			Bracket, Cabinet
5	3396795			Cover, Terminal Block
6	342043	486146		Screw
7	3396805	280043		Panel-Rear
8	3393008	308685		Side Trim)
9	3390731			Seal, Door
10	3406109	3406107		Door Switch Assembly
11	697773	3395530		Screw
12	3404162			Clamp, Motor
13	3357011	308685		Side Trim)
14	W10041960			Spring, Door

15	3394083		Clip, Front Panel
16	3392100	49621	Feet-Leveling
NI	279810		Foot-Optional
17	279318		Terminal Tinned And Brass Panel
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	8066092		Lock, Front Top
21	695620	279443	Panel
22	W10121316		Plug, Multivent
23	685203	279220	Clip
24	3389441		Door Catch Assembly
25	W10289660	W10416572	Motor-Drve
26	337189		Clip, Hinge
27	342055	488627	Screw
28	8066056		Hinge, Door
"	8066057		Hinge, Door
29	690046	Not Available	SCREW, SET 1/4 - 28 X 3/8
30	3400500		Bolt, 3405245 5/16-18 X 3/4
31	348780		Base, Motor
32	W10131364	341241	Belt
33	696144	279570	Latch
34	691366		Idler And Pulley Assembly
35	695737		Door, Rear
36	3393549		Door, Front
37	W10095180		Handle, Door
38	3406129		Seal And Bearing Assembly
39	279393		Terminal Block Screw Kit
40	3390631		Screw, 10-16 X 3/8
41	3397659		Block, Terminal
42	8066217		Hinge, Top
43	685011		Pulley, 60 Hz

