


# Whirlpool 4GWED5500YW0 01 - TOP AND CONSOLE PARTS



Whirlpool [Residential Whirlpool 4GWED5500YW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10461694		Not Available	INSTALLATION INSTRUCTIONS
"	W10461693		Not Available	GUIDE, USE & CARE
"	W10417013		Not Available	TECH SHEET
2	<a href="#">W10344471</a>			Console Assembly
3	<a href="#">W10251392</a>			Knob Assembly
4	<a href="#">W10362634</a>			User Interface Assembly
5	<a href="#">W10325119</a>			Spacer, Knob
6	<a href="#">W10274524</a>			Tensioner, Facia
7	<a href="#">W10279552</a>			Plug-Upper Rear Panel
8	<a href="#">W10298336</a>			8-18 Nch, U-Type NUT
9	<a href="#">W10096969</a>			Panel, Rear Console
10	8533971	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">W10260246</a>			Top
12	<a href="#">W10346523</a>			CCU-Control
13	3390647	<a href="#">488729</a>		Screw

14	<a href="#">8312709</a>		Clip-Console
15	W10286180	<a href="#">W10119283</a>	Cover, Terminal Block
16	<a href="#">W10271580</a>		Bracket, Motor Control
17	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
18	<a href="#">8536939</a>		Clip, Knob
19	<a href="#">W10339708</a>		Harness, Electric
20	<a href="#">W10123956</a>		Dampening Panel
21	<a href="#">W10323092</a>		Seal, User Interface
22	<a href="#">W10280079</a>		Seal, Console

