


# Whirlpool 4GWTW4740YQ0 02 - CONTROLS AND WATER INLET PARTS

## CONTROLS AND WATER INLET PARTS

For Model: 4GWTW4740YQ0  
(White)



W10469259

3

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Whirlpool [Residential Whirlpool 4GWTW4740YQ0 Washer Parts](#) Parts Diagram 02 - CONTROLS AND WATER INLET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10365091</a>			Panel, Console
2	<a href="#">8536939</a>			Clip, Knob
3	8566035	<a href="#">8565957</a>		Cap, End
4	8566032	<a href="#">8565954</a>		Cap, End
5	<a href="#">8312709</a>			Clip-Console
6	<a href="#">W10446367</a>			Control Unit Assembly, Machine And Motor
7	<a href="#">W10420985</a>			Panel, Console Rear Cover
8	1157158	<a href="#">489069</a>		Xxscrew, 10-12 X 1/2
9	<a href="#">W10268910</a>			Switch, Water Level
10	<a href="#">90767</a>			Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">W10422755</a>			Cord, Power
NI	N/P		Not Available	(PARTS NOT SHOWN)
"	<a href="#">W10153836</a>			10A Cord Lock
"	<a href="#">W10223804</a>			10A Cord, Adapters

"	<a href="#">W10223809</a>		10A Cord Adapters
"	<a href="#">W10223807</a>		10A Cord Adapters
12	<a href="#">3400076</a>		Screw, Bracket Mounting
13	<a href="#">W10034750</a>		Timer Knob Assembly
14	<a href="#">W10034380</a>		Knob, Control
15	<a href="#">W10285511</a>		Switch, Rotary Encoder
16	<a href="#">W10291178</a>		Harness, Upper
17	<a href="#">W10337066</a>		Inlet Assembly, Water
18	W10336726	Not Available	VALVE, WATER MIXING
19	<a href="#">W10441423</a>		Vacuum Break
20	<a href="#">W10238347</a>		Hose, Vacuum Break
21	W10117298	<a href="#">596669</a>	Clamp, Manifold
22	W10337345	<a href="#">W10344775</a>	Harness, Valve
23	<a href="#">8281163</a>		Screw, Dispenser Housing Mounting
24	<a href="#">3400818</a>		Screw, Timer Mounting
25	<a href="#">W10348582</a>		Cable Tie
26	<a href="#">W10251309</a>		Pushbutton, Start
27	W10242307	<a href="#">16123</a>	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
28	W10194210	<a href="#">89503</a>	Hose-Inlet
"	W10196191	<a href="#">89503</a>	Hose-Inlet
29	353362	<a href="#">285452</a>	Hose Screen
30	<a href="#">W10269488</a>		Connector- Hose, Y
31	<a href="#">3357450</a>		Washer, Water Inlet Hose

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>